

The recommended cleaning process for all WAVE ID® Solo and WAVE ID® Plus desktop and surface mount readers is using a clean, soft cloth dampened with mild soap and water, gently wiping away any dust or dirt. Alternatively, one of the cleaning methods shown below may be used.

Clorox® Disinfecting Wipes

Super Sani-Cloth®

Sani-Cloth® AF3

Clorox® Dispatch® Disinfectant Wipes

CaviWipes™

SONO® Ultrasound Wipes



Test Results of Disinfectants and Cleansers applied to WAVE ID® Solo and WAVE ID® Plus Desktop and Surface Mount Readers

Disinfectant or Cleanser	Pass	Fail	Methodology
Clorox Disinfecting Wipes	X		Rubbed vigorously.
Super Sani-Cloth	X		Per recommended application.
Sani-Cloth AF3	X		Per recommended application.
Clorox Dispatch Disinfectant Wipes	X		Per recommended application.
CaviWipes	X		Per recommended application.
SONO Ultrasound Wipes	X		Per recommended application.

Tests were performed at rf IDEAS by the Quality Department.

If you have support questions, please email us at TechSupport@rfIDEAS.com or call 866-492-8231.

rf IDEAS® and WAVE ID® are registered trademarks of rf IDEAS, Inc. All other trademarks, service marks, and product or service names are property of their respective owners.

